

01-01-05-0001    01-01-05-1002    01-01-05-0002    01-01-05-0003    01-01-05-0004  
 MP25            MP25            MP25            MP25            MD35

partnr.	Part name(single function wire)	label on wire	Colors	wire sizes (mm2)	4cylinder	V6	6-line	8cylinder	4cylinder
01-01-05-4001	Lambda 1	Lambda 1	white/red/black	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4002	Lambda 2	Lambda 2	white/red/black	0,5/0,5/0,5					
01-01-05-4003	Injection (1-2-3)	Injection 1	red/white	0,75/0,75					
01-01-05-4004	Injection (4-5-6)	Injection 2	red/white	0,75/0,75					
01-01-05-4005	Injection (1-2-3-4)	Injection 1	red/white	0,75/0,75	1			1	1
01-01-05-4006	Injection (5-6-7-8)	Injection 2	red/white	0,75/0,75				1	
01-01-05-4007	Injection (1-2-3-4-5)	Injection	red/white	0,75/0,75					
01-01-05-4008	Injection (1-2-3-4-5-6)	Injection	red/white	0,75/0,75			1		
01-01-05-4009	Injection (123-456 V)	Injection	red/white	0,75/0,75		1			
01-01-05-4010	Ignition (1-2)	Ignition	red/orange/green	0,75/0,5/0,5	1				1
01-01-05-4011	Ignition (1-2-3)	Ignition	red/orange/green/purple	0,75/0,5/0,5/0,5		1	1		
01-01-05-4012	Ignition (4-5-6)	Ignition 2	red/blue/pink/yellowgreen	0,75/0,5/0,5/0,5					
01-01-05-4013	Ignition 4	Ignition	red/orange/green/purple/pink	0,75/0,5/0,5/0,5/0,5				1	
01-01-05-4014	Ignition 5	Ignition	red/orange/green/purple/pink/blue	0,75/0,5/0,5/0,5/0,5/0,5					
01-01-05-4015	Water temperature	Water T	greyblue/black	0,5/0,5	1	1	1	1	1
01-01-05-4016	Air temperature	Air T	redblue/black	0,5/0,5	1	1	1	1	1
01-01-05-4017	TPS (throttle position sensor)	TPS	yellow/grey/black	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4018	MAP (manifold/Air pressure)	MAP	yellow/greyblack/black	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4019	Crank sensor	Crank	red/blue/shielding (black)	0,5/0,5/shielding	1	1	1	1	1
01-01-05-4020	Hall effect sensor	Hall	yellow/black/redgreen	0,5/0,5/0,5					1
01-01-05-4021	Boost solenoid	Boost	orangeblack/red	0,5/0,5					1
01-01-05-4022	Idle control valve	Idle	yellowred/red	0,5/0,5					1
01-01-05-4023	Analog 2 (map select/gear pos.)	Analog 2	yellow/black/orangered	0,5/0,5/0,5					1
01-01-05-4024	Communication RS232	Communication	red/green	0,5/0,5					
01-01-05-4025	Extra wire set MP25		various	various	1	1	1	1	
01-01-05-4026	Extra wire set MD35		various	various					1
01-01-05-4027	CAN-communication	CAN-communication	red/green	0,5/0,5					1
01-01-05-4028	EGT kit	EGT	red/orangered/black	0,5/0,5/0,5					1
01-01-05-4029	Oil Pressure sensor	Oil.P	yellow/pinkblack/black	0,5/0,5/0,5					1

01-01-05-0005 01-01-05-0006 01-01-05-0007 01-01-05-0008 01-01-05-0009  
 MD35 MD35 MD35 MD35 MD35

partnr.	Part name(single function wire)	label on wire	Colors	wire sizes (mm2)	4cylinder DF	4cylinder ST	4cylinder ST+DF	5cylinder	5cylinder ST
01-01-05-4001	Lambda 1	Lambda 1	white/red/black	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4002	Lambda 2	Lambda 2	white/red/black	0,5/0,5/0,5					
01-01-05-4003	Injection (1-2-3)	Injection 1	red/white	0,75/0,75					
01-01-05-4004	Injection (4-5-6)	Injection 2	red/white	0,75/0,75					
01-01-05-4005	Injection (1-2-3-4)	Injection 1	red/white	0,75/0,75	1	2	2		
01-01-05-4006	Injection (5-6-7-8)	Injection 2	red/white	0,75/0,75					
01-01-05-4007	Injection (1-2-3-4-5)	Injection	red/white	0,75/0,75				1	2
01-01-05-4008	Injection (1-2-3-4-5-6)	Injection	red/white	0,75/0,75					
01-01-05-4009	Injection (123-456 V)	Injection	red/white	0,75/0,75					
01-01-05-4010	Ignition (1-2)	Ignition	red/orange/green	0,75/0,5/0,5		1			
01-01-05-4011	Ignition (1-2-3)	Ignition	red/orange/green/purple	0,75/0,5/0,5/0,5					
01-01-05-4012	Ignition (4-5-6)	Ignition 2	red/blue/pink/yellowgreen	0,75/0,5/0,5/0,5					
01-01-05-4013	Ignition 4	Ignition	red/orange/green/purple/pink	0,75/0,5/0,5/0,5/0,5	1		1		
01-01-05-4014	Ignition 5	Ignition	red/orange/green/purple/pink/blue	0,75/0,5/0,5/0,5/0,5/0,5				1	1
01-01-05-4015	Water temperature	Water T	greyblue/black	0,5/0,5	1	1	1	1	1
01-01-05-4016	Air temperature	Air T	redblue/black	0,5/0,5	1	1	1	1	1
01-01-05-4017	TPS (throttle position sensor)	TPS	yellow/grey/black	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4018	MAP (manifold/Air pressure)	MAP	yellow/greyblack/black	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4019	Crank sensor	Crank	red/blue/shielding (black)	0,5/0,5/shielding	1	1	1	1	1
01-01-05-4020	Hall effect sensor	Hall	yellow/black/redgreen	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4021	Boost solenoid	Boost	orangeblack/red	0,5/0,5	1	1	1	1	1
01-01-05-4022	Idle control valve	Idle	yellowred/red	0,5/0,5	1	1	1	1	1
01-01-05-4023	Analog 2 (map select/gear pos.)	Analog 2	yellow/black/orangered	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4024	Communication RS232	Communication	red/green	0,5/0,5					
01-01-05-4025	Extra wire set MP25		various	various					
01-01-05-4026	Extra wire set MD35		various	various	1	1	1	1	1
01-01-05-4027	CAN-communication	CAN-communication	red/green	0,5/0,5	1	1	1	1	1
01-01-05-4028	EGT kit	EGT	red/orangered/black	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4029	Oil Pressure sensor	Oil.P	yellow/pinkblack/black	0,5/0,5/0,5	1	1	1	1	1

01-01-05-0010 MD35    01-01-05-0011 MD35    01-01-05-0012 MD35    01-01-05-0013 MD35    01-01-05-0014 MD35

partnr.	Part name(single function wire)	label on wire	Colors	wire sizes (mm2)	6cylinder	6cylinder DF	6cylinder ST	6cylinder ST+DF	8cylinder
01-01-05-4001	Lambda 1	Lambda 1	white/red/black	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4002	Lambda 2	Lambda 2	white/red/black	0,5/0,5/0,5	1	1			1
01-01-05-4003	Injection (1-2-3)	Injection 1	red/white	0,75/0,75	1	1			
01-01-05-4004	Injection (4-5-6)	Injection 2	red/white	0,75/0,75	1	1			
01-01-05-4005	Injection (1-2-3-4)	Injection 1	red/white	0,75/0,75					1
01-01-05-4006	Injection (5-6-7-8)	Injection 2	red/white	0,75/0,75					1
01-01-05-4007	Injection (1-2-3-4-5)	Injection	red/white	0,75/0,75					
01-01-05-4008	Injection (1-2-3-4-5-6)	Injection	red/white	0,75/0,75			2	2	
01-01-05-4009	Injection (123-456 V)	Injection	red/white	0,75/0,75					
01-01-05-4010	Ignition (1-2)	Ignition	red/orange/green	0,75/0,5/0,5					
01-01-05-4011	Ignition (1-2-3)	Ignition	red/orange/green/purple	0,75/0,5/0,5/0,5	1	1	2	1	
01-01-05-4012	Ignition (4-5-6)	Ignition 2	red/blue/pink/yellowgreen	0,75/0,5/0,5/0,5		1		1	
01-01-05-4013	Ignition 4	Ignition	red/orange/green/purple/pink	0,75/0,5/0,5/0,5/0,5					2
01-01-05-4014	Ignition 5	Ignition	red/orange/green/purple/pink/blue	0,75/0,5/0,5/0,5/0,5/0,5					
01-01-05-4015	Water temperature	Water T	greyblue/black	0,5/0,5	1	1	1	1	1
01-01-05-4016	Air temperature	Air T	redblue/black	0,5/0,5	1	1	1	1	1
01-01-05-4017	TPS (throttle position sensor)	TPS	yellow/grey/black	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4018	MAP (manifold/Air pressure)	MAP	yellow/greyblack/black	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4019	Crank sensor	Crank	red/blue/shielding (black)	0,5/0,5/shielding	1	1	1	1	1
01-01-05-4020	Hall effect sensor	Hall	yellow/black/redgreen	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4021	Boost solenoid	Boost	orangeblack/red	0,5/0,5	1	1	1	1	1
01-01-05-4022	Idle control valve	Idle	yellowred/red	0,5/0,5	1	1	1	1	1
01-01-05-4023	Analog 2 (map select/gear pos.)	Analog 2	yellow/black/orangered	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4024	Communication RS232	Communication	red/green	0,5/0,5					
01-01-05-4025	Extra wire set MP25		various	various					
01-01-05-4026	Extra wire set MD35		various	various	1	1	1	1	1
01-01-05-4027	CAN-communication	CAN-communication	red/green	0,5/0,5	1	1	1	1	1
01-01-05-4028	EGT kit	EGT	red/orangered/black	0,5/0,5/0,5	1	1	1	1	1
01-01-05-4029	Oil Pressure sensor	Oil.P	yellow/pinkblack/black	0,5/0,5/0,5	1	1	1	1	1